

PARTS LIST FOR THE SPROUL WOBBLE MOTOR (W16 R MOTOR)

APRIL
2008


#1W16	MOUNTING BODY
#2W16R	PISTON BODY
#3W16R	VALVE CAP
#4W16	SHAFT
#5W16	SHAFT SEAL
#6W16	6201 X 1/2 BEARING
#7W16	1/8 X 1/2 SPRING PIN
#8W16	EXCENTRIC BODY
#9W16	BALANCING WHEEL
#10W16	6905 BEARING
#11W16	WOBBLE PLATE
#12W16	PISTON SLEEVE
#13W16R	VALVE BODY
#14W16CCWR	VALVE
#14W16CWR	VALVE
#15W16	PISTON
#16W16	PISTON SEAL
#17W16	VALVE POP IN
#18W16	SEAL
#19W16	SPRING
#20W16	131 N70 O-RING
#21W16	#10X32X1" SOC HEAD CAP SCREW
#23 823M4	1 4 MUFFLER COMPLETE
#24 823MC	MUFFLER THREAD ON CAP
#25 823MF	MUFFLER FELT
#26 823MB	MUFFLER BODY
#27W16	131-N70 O-RING
#28W16	PISTON TIP (TIP ONLY)

(W16R MOTOR) IS A 66 PLSTON MOTOR
1 BORE X .600 STROKE
MOTOR OUT OF BOX WILL RUN CW
YOU CAN RUN THE MOTOR CCW BY
CHANGEING THE VALVE
CCW VALVE WILL BE INCLOSED
WITH EVERY MOTOR

MAX SPEED * * * 1800
14 C.F.M. AT 60 P.S.I.
H.P. - - - - 1/3

ALWAYS USE GOOD FILTERS AND LUBRICATO
FOR BEST RESULTS USE A
MICOR MIST LUBRICATOR AND
A COALESCER FILTER
THIS WILL INCREASE THE LIFE
OF YOUR MOTOR



PRICE SUBJECT TO CHANGE
WITHOUT NOTICE



BRACKETS AND ACESSORIES FOR THE (W16 R MOTOR)


APRIL
2008

#WMA WASHMACHINE MOUNT ACESSORIES
#3212 3 1/4 X 1/2 BORE PULLEY
#A26 BELT
W16R WK MOTOR @ ACESSORIES FOR WASHMACHINE
#W16R-CM CEILING MOUNT SET OF 2PC.
#W16R-BB BAND BRACKET



FOR WASHMACHINE
RUN MOTOR ABOUT 1700 R.P.M.
TAKES ABOUT 10 TO 14 G.F.M.
AGITATOR SHOULD MAKE APROXIMATELY
55 STROKES PER. MIN.

NOTICE
DO NOT OVER TIGHTEN AIR FITTING
JUST A LITTLE MORE THAN HAND TIGHT



WMA
COMES WITH STAINLESS STEEL
BOLTS NUTS AND WASHERS AND 2 STEEL PLATES

THE 6 X 890 HM BRACKET CAN BE USED ON A LOT DIFFERENT APPLICATIONS